

ENGINEERING DOCUMENTATION

High-Torque Hollow Shaft Gear Unit

Dimensional & Integration Guide

DOCUMENT	REVISION / ISSUE	STATUS
DIG-ES-HG-S09-F40-R120	DRAFT-08 / 26 Aug 2026	Engineering Integration Reference

Integration Overview


Hollow-shaft harmonic gear gear unit with integrated product interfaces for the selected configuration for compact, coaxial, high-ratio rotary axes. This guide supports host-interface design, wave-generator input integration, mounting alignment, load-cycle validation, torsional behavior, lubrication, sealing and commissioning for ES-HG-S09-F40-R120.

Key Integration Facts


INTEGRATION ITEM	PUBLISHED VALUE
Rated Torque	382 Nm
Instantaneous Maximum Torque	1530 Nm
Start/Stop Peak Torque	802 Nm
Reduction Ratio	120
Maximum Input Speed	4000 r/min
Frame Size	40
Weight	7.2 kg

Product Structure & Views


These views present the selected product structure, mounting interfaces and relevant integration geometry for this SKU.



Mechanical View 1



Mechanical View 2



Mechanical View 3

VIEW	FIELD	VALUE
Mechanical View 1	Overall width	79 mm
	Intermediate step width	64 mm
	Inner step width	38 mm
	Right minor step width	7 mm
	Right step dimension	13 mm
	Left inner step depth	14 mm
	Central axial dimension	32 mm
	Lower step axial dimension	12 mm
	Outer diameter max with tolerance	Ø75 h7
	Second outer diameter with tolerance	Ø59 h7
	Left bore diameter with fit	Ø6 H7
	Right bore diameter with fit	Ø6 H7
	Right mid outer diameter with tolerance	Ø00 h7
	Right large outer diameter with tolerance	Ø70 h7
	Flange intermediate circle diameter	Ø40
Mechanical View 2	12 evenly distributed mounting holes diameter	12 holes, Ø.5 mm
	Outer flange diameter	Ø58 mm
	Center pilot bore diameter	Ø2 mm
	6 threaded holes M4	6 holes, M4 thread
	Threaded hole depth	8 mm depth
Mechanical View 3	Outer mounting hole pattern (quantity and diameter)	16 holes, Ø.5 mm
	Outer mounting hole pattern (quantity and thread)	16 holes, M6 thread
	Outer mounting hole counterbore depth	Counterbore depth 25 mm
	Outer mounting hole depth	Hole depth 10 mm
	Outer diameter	Ø22 mm
	Center mounting hole diameter	Ø2 mm
	Inner mounting hole pattern (quantity and thread)	6 holes, M4 thread
	Inner mounting hole counterbore depth	Counterbore depth 8 mm

Overall Dimensions and Input Interface

PARAMETER	PUBLISHED VALUE	UNIT
Frame Size	40	
Weight	7.2	kg

- Confirm the selected series, frame size and ratio before using dimensions or interface geometry. Do not substitute a nearby frame or product form.
- Design the input shaft, key, effective engagement and axial retention to transmit the verified torque without uncontrolled wave-generator axial movement.
- Reserve assembly, sealing, inspection and removal access around the input, housing and output interfaces.

Mounting, Alignment and Fastener Control

- Keep mounting faces flat, clean and free of burrs, raised holes, debris and coating buildup. Confirm reliefs and chamfers prevent interference.
- Seat the fixed and flexible gear members in the host structure before inserting the wave generator. Do not force engagement in a misaligned condition.
- Control concentricity, tilt and axial position of the input and housing datums. Insert the wave generator smoothly without excessive force on its bearing.
- Tighten fasteners in a staged diagonal sequence using the applicable torque and locking specification. Verify free, even rotation during assembly.

Torque, Speed and Duty Boundaries

PARAMETER	PUBLISHED VALUE	UNIT
Rated Torque	382	N·m
Allowable Average Torque	586	N·m
Start/Stop Peak Torque	802	N·m
Instantaneous Maximum Torque	1530	N·m
Maximum Input Speed	4000	r/min
Average Input Speed	3000 / 3500	r/min
Design Life	15000	h

- Calculate average torque and average input speed from the complete acceleration, constant-speed, deceleration, dwell and reversal cycle.
- Treat start/stop peak and instantaneous maximum torque as transient boundaries. Do not use either value as a continuous operating point.
- Validate design life against actual torque, speed, shock frequency, lubrication, temperature, alignment and external loading.

Published Torque, Speed and Life Boundaries

PARAMETER	PUBLISHED VALUE	INTEGRATION REQUIREMENT
Rated Torque	382 N·m	Use as the selected continuous output rating under validated duty and thermal conditions.
Allowable Average Torque	586 N·m	Calculate the actual time-weighted output torque over the complete cycle.
Start/Stop Peak Torque	802 N·m	Transient start/stop boundary; include acceleration and deceleration events.
Instantaneous Maximum Torque	1530 N·m	Short-duration shock boundary only; do not use as a normal operating point.
Maximum Input Speed	4000 r/min	Maximum input-speed boundary; also verify motor and thermal limits.
Average Input Speed	3000 / 3500 r/min	Validate the time-weighted average input speed over the complete duty cycle.
Design Life	15000 h	Design reference only; actual life depends on torque, speed, shock, lubrication and installation.

Transmission Accuracy and Torsional Rigidity

PARAMETER	PUBLISHED VALUE	UNIT
Angle Transmission Accuracy	1	arcmin
Hysteresis Loss	1	arcmin
Torsional Rigidity K1	13	$\times 10^4 \text{Nm/rad}$
Torsional Rigidity K2	20	$\times 10^4 \text{Nm/rad}$
Torsional Rigidity K3	23	$\times 10^4 \text{Nm/rad}$
Torsional Rigidity T1	54	Nm
Torsional Rigidity T2	196	Nm

- Installed positioning performance depends on reducer behavior, datum control, fastener distortion, motor and encoder errors, host stiffness and thermal growth.
- Use the published stiffness regions and transition torques when evaluating compliance, resonance, control gain and direction reversal.

Published Accuracy and Torsional Rigidity Boundaries

PARAMETER	PUBLISHED VALUE	INTEGRATION REQUIREMENT
Angle Transmission Accuracy	1 arcmin	Installed system accuracy also depends on datum, encoder, motor and structural errors.
Hysteresis Loss	1 arcmin	Include in direction-reversal and closed-loop positioning evaluation.
Torsional Rigidity K1	$13 \times 10^4 \text{Nm/rad}$	Applies to the published low-torque stiffness region.
Torsional Rigidity K2	$20 \times 10^4 \text{Nm/rad}$	Applies to the published intermediate stiffness region.
Torsional Rigidity K3	$23 \times 10^4 \text{Nm/rad}$	Applies to the published upper stiffness region.
Torsional Rigidity T1	54 Nm	Published transition torque for stiffness-region interpretation.
Torsional Rigidity T2	196 Nm	Published transition torque for stiffness-region interpretation.

Lubrication, Sealing and Thermal Control

- Use only the current lubricant, fill method and quantity for the exact configuration. Do not mix incompatible lubricants.
- Provide compatible static and dynamic sealing at the input, output and housing interfaces without distorting the reducer or restricting motion.
- Validate lubricant distribution and temperature for the installed orientation, speed, load cycle and enclosure.
- Prevent chips, fibers, cleaning residue, moisture and other contamination from entering the gear or bearing cavities during assembly and service.

Output Bearing and External Load Path

- Calculate radial, axial and moment loads at the output, including offset, acceleration, gravity, process force, impact and emergency-stop cases.
- Do not infer permissible external load from reducer torque capacity or frame size. Use applicable output-bearing data and safety criteria.
- Avoid forcing, impact, misalignment or host distortion through the output support bearing during installation and operation.

Integration Checklist

- 01 Confirm the drawing, published parameters and applicable assembly data identify this SKU.
- 02 Verify series, frame size, ratio, product form and input-interface dimensions.
- 03 Check mounting-face flatness, concentricity, tilt, chamfers, reliefs, cleanliness and support stiffness.
- 04 Verify input shaft, key, engagement length and axial wave-generator retention.
- 05 Assemble the fixed and flexible gear members before inserting the wave generator.
- 06 Use staged diagonal tightening and verify free, even rotation throughout assembly.
- 07 Calculate average, start/stop peak and shock torque over the complete operating cycle.
- 08 Validate average and maximum input speed, design life and installed thermal condition.
- 09 Evaluate backlash, angular accuracy, hysteresis and stiffness regions for the control system.
- 10 Confirm exact lubricant, fill quantity, orientation, sealing and contamination controls.
- 11 Validate output radial, axial and moment loads using applicable bearing data.
- 12 Include specified 2D, STEP, assembly, lubrication and bearing-load data in integration planning.

[View SKU Product Datasheet](#) [Request controlled 2D drawing](#) [Request controlled STEP review](#) [Request a Quote](#)

Engineering Use and Verification Notice

01. This Dimensional & Integration Guide applies only to EmbodyStack SKU ES-HG-S09-F40-R120 and is intended for dimensional evaluation and preliminary integration. It is not a applicable manufacturing drawing, reducer selection approval, bearing-load approval, lubrication specification, machinery risk assessment, safety validation or integration planning document and must not be used as the sole basis for machining, shaft or key manufacture, fastener selection, sealing, lubricant filling or final integration. Before design freeze, assembly or commissioning, verify all dimensions, datum geometry, fits, shaft and key interfaces, wave-generator retention, fastener engagement and tightening controls, torque and speed duty, shock cases, torsional accuracy and rigidity, external output loads, lubrication, sealing, temperature, contamination and maintenance requirements against the applicable EmbodyStack engineering data for this exact SKU. Where this guide and applicable product documentation differ, the applicable product documentation governs. Validate the complete reducer, motor, host structure, output load, motion cycle, guarding, fault cases and applicable regulatory requirements under intended operating conditions.